



Servoübersicht Futaba LV / HV

Stand 10-04-2013

Dicke	LV = low volt 4,8...6 Volt			HV = high volt 6...8,4 Volt			Motor	Kategorie
	Std. LV	LV-S.BUS	LV-S.BUS2	HV-Servo	HV-S.BUS	HV-S.BUS2		
8 mm	FS31 Pi.						3-pol	Std.
9 mm	FS40 Pi.						3-pol	Std.
10 mm							3-pol	Std.
10,8 mm	S3150	S3171SB				S3172SV	3-pol	Std.
	S3155					S3174SV		
						S3173SVi		
11 mm	S3107						3-pol	Std.
	S3114							
	S3117							
	S3157							
	S3154							
S3156								
12 mm							3-pol	Std.
13 mm	S3115						3-pol	Std.
							BLS	Profi
15 mm							3-pol	Std.
	S9650	S9071SB					9-pol	Leistung
	BLS153					BLS173SV/Svi	BLS	Profi
	BLS651						BLS	Profi
20 mm Universal	FS100						3-pol	Std.
	S148							
	S3003							
	S3001							
	S3151							
	S3152					S3072HV-SB		
	S3010							
	S3050					S3070HV-SB		
	S3305				S3051HV	S3071HV-SB		
	S9202							
		S9072SB						
S9026					S9070SB	S9170SV	9-pol	Leistung
Car	S9551						9-pol	Leistung
				S9352HV				
				S9353HV				
	BLS451						BLS	Profi
	BLS452							
	BLS351							
BLS352								
BLS551								
Heli		S9072SB					9-pol	Leistung
	S9452							
	BLS253			BLS252HV	BLS272HV-SB	BLS272SV	BLS	Profi
	BLS252					BLS273SV		
Flugmodell		S9074SB					9-pol	Leistung
		S9075SB						
	BLS155			BLS156HV	BLS175HV-SB	BLS175SV	BLS	Profi
	BLS152			BLS157HV	BLS172HV-SB	BLS172SV		
						BLS177SV		
Heck 15 mm	S9257						9-pol	Leistung
	BLS257					BLS277SV	BLS	Profi
Heck 20 mm	S9254						9-pol	Leistung
	BLS254					BLS274SV	BLS	Profi
	BLS251			BLS256HV		BLS276SV		